

## No power to to the E800 bays (Green LED is not lit)

- The backplane of the drive bays is designed with a Molex power connector, and it is possible that it could get loose during shipping.
  - Ensure that the drives are properly seated to the backplane connector,
- The 3Amp Fast Acting fuse (if equipped) may have been blown.
  - Make sure that the 3Amp fuse(s) are not blown (if equipped).
  - Replace the blown fuse(s) (if equipped) - refer to [E800 safety features](#).