


BlanccoGRUB

20 May 2020		Hardware Appliance 6.11.1	N/A


Blancco (8-Bay, 24-Bay, Array Server Eraser) GRUB:_Drive Eraser HW Edition

BIOS 3.2

- 1. Rufus6.11.1 HW editionUSB
- 2. DeleteBIOS
- 3. Advanced SATA ConfigurationSATA FrozenDisabled




- 4. UEFI: External USB drive (USB)




- 5. INSTALL (1,2,3,4) 6.11.1
- 6. USB
- 7. DeleteBIOS
- 8. :


- Boot Hard Disk Drive BBS Priorities 1st Device = Disabled



- Boot UEFI Boot Drive Disk Drive BBS Priorities 1st Device = GRUB



- Boot Set Boot Priority 1st Boot Device = UEFI GRUB



- 9.
- 10. 6.11.1 HW edition