

# Clear Device cards from Blancco Mobile Device Diagnostic and Erasure UI

Created date	Updated date	Affects version	Fix version
26 Aug 2021	01 Sep 2021	Mobile Diagnostics and Erasure - 4.8.1	Mobile Diagnostics and Erasure - 4.9


## Description

Blancco Mobile Diagnostic and Erasure 4.8.1 version device cards behavior has changed. On Blancco Mobile Diagnostic and Erasure 4.8.1 device cards are more sticky on the user interface. Once the device process is ready, either the user has to use 'x' button to remove a device card from UI or use dismiss option via Execute button to remove multiple device cards at once.

The change in Device card feature has an affect to following items in Blancco Mobile Diagnostic and Erasure 4.8.1 version:

Workflow:

- Send Report item.
  - Send Report item will send a report to Management Console/[cloud.blancco.com](https://cloud.blancco.com).
  - Report is shown as an unprocessed report in Blancco Mobile Diagnostic and Erasure Reports view.



Settings:

- General
  - "Autosend reports to Blancco Management Console when cable is disconnected"
- Printer
  - "Number of labels to be printed when device is removed after erasure"
  - "Enable custom printing"
    - "Remove"

Blancco Mobile Diagnostic and Erasure 4.8.1 Send and Print actions under settings are done when the device card is removed.

On Blancco Mobile Diagnostic and Erasure 4.8.0 and older above actions are done when the device is disconnected.

## Step by step instructions


### For removing Device card user can either:

- Remove Device card from Blancco Mobile Diagnostic and Erasure UI by Pressing "x" on the device card.

View: **List** **Grid** Free Slot Sheet




- Remove Multiple dismissed devices from the UI via Execute button.



In order to have "Execute, allow bulk dismiss" option available in Execute button the option has to be enabled from system settings.

1. To access system settings press gear icon from login screen.



## 2. Select Admin Control.

# System settings

- Set Network
- Set Proxy
- Set Network Test
- Set Time and Date
- Synchronization Service
- Storage Cleanup
- **Admin Control**
- Display
- Browser
- Preconfiguration
- Updates
- Uninstallation

## Admin control

Input admin password

|

## 3. Adjust user permissions; Other Restrictions.

# System settings

- Set Network
- Set Proxy
- Set Network Test
- Set Time and Date
- Synchronization Service
- Storage Cleanup
- **Admin Control**
- Display
- Browser
- Preconfiguration
- Updates
- Uninstallation

## Adjust user permissions

Default user

User permissions

Other restrictionsLogin screen

Miscellaneous settings affecting given user

Set to all users

Android whitelisting:☐

Change diagnostics set:☒

Change erasure standard:☒

Change process:☒

Change processing face:☒

Confirm version update:☒

Dismiss query at connect:☐

Execute, allow bulk cancel:☐

Execute, allow bulk clear Prolog KV-store:☐

Execute, allow bulk dismiss:☒

Execute, allow bulk shutdown:☐

Execute, allow select devices that failed to process:☐

Execute, allow select processed devices:☐

Ignore SIM removal:☐

Modify sheet view:☒

Set USB controller limits:☒

4. Enable "Execute, allow bulk dismiss".

