

Blanco Drive Eraser 7.5.0 Drive Eraser Configuration Tool

3.5.0

:

- ALBUS-8114, ALBUST-1027 -
- ALBUS-6565, ALBUST-1025 -
- ALBUS-6773, ALBUST-1028, WFE-207 - SIM
- ALBUS-9060, ALBUST-1022 - LenovoSID
- ALBUS-9142, WFE-208 -
- ALBUST-473, ALBUST-941, ALBUST-1036 - Configuration Tool:

:

- ALBUS-9392 - Sanitize Overwrite(SOW)16SOW
- ALBUS-9450 - SOW
- ALBUS-9393 -
- ALBUS-9558 - 2
 -
- ALBUS-9508 -
 -
- ALBUS-9513 -
- ALBUS-8684 -
- ALBUS-8918 - Intel Optane NVMe
- ALBUS-9376 -
- ALBUS-9490 -
- ALBUS-9446 - HP EliteBook 850 G8IP
- ALBUS-9504, ALBUS-9437, ALBUS-9443, ALBUS-9462 - HP G7HP G8PC(EliteBook, ProBook)Intel11PC
- ALBUS-8038, ALBUS-9432 - Realtek RTL8822CERTL8821CERTL8822BEWi-Fi
- ALBUS-9516 - Surface Pro 4Wi-Fi(88W8897 [AVASTAR] 802.11ac Wireless)
- ALBUS-9286 -
 - 21
- ALBUS-9378 - SeagateBackup Plus4TBUSB
 -
- ALBUS-9436 - Intel11CPUPC
- ALBUS-9540 -
- ALBUS-8405 - Blanco Management Console
- ALBUS-8441 - BDECD
- ALBUS-8923 - Chromebook
- ALBUS-9395 -
- ALBUS-8309, ALBUS-8323, ALBUS-8426, ALBUS-8736, ALBUS-9025, ALBUS-9225, ALBUS-9402, ALBUS-9426, ALBUS-9427 - 255HEX
- ALBUS-8255, ALBUS-8269, ALBUS-8279, ALBUS-9198, ALBUS-9195 -
- ALBUST-1001, ALBUST-1014, ALBUST-1016, ALBUST-930, ALBUST-1062 - BDECT%1