

Blancco Drive Eraser

Blancco Drive Eraser/Blancco 5CD(Blancco - Certified Data ErasureStarting Blancco Drive EraserStarting Blancco 5)5USBGrub

1. Normal startup (safe resolution) – 1024×768()*()*
2. Normal startup (native resolution) – *()*(1024 x768)*()*
3. FLR during startup – (1024 x768)
4. Show startup messages – 2Normal startup (native resolution)
5. Customized startup – *()*Blancco Drive Eraser 6.3.0Blancco Drive Eraser Configuration Tool 2.3.0 Blancco Drive Eraser Configuration Tool